






CUOCIPASTA • PASTA COOKER • CUISEUR • NUDELKOCHER

CS 1/1 Cod. 31613700	Basket 1/1	290 x 330 x 200 (h) mm	
CS 1/2 Cod. 31613600	Basket 1/2	140 x 330 x 200 (h) mm	
CS 1/3 Cod. 31613800	Basket 1/3	290 x 105 x 200 (h) mm	
CS 1/6 DX Cod. 31613900	Basket 1/6	140 x 105 x 200 (h) mm	
CS 1/6 SX Cod. 31614500	Basket 1/6	140 x 105 x 200 (h) mm	
C1 Cod. 31613700	Combination 1 Basket 1/1		CS 1/1
C2 Cod. 31614000	Combination 2 Baskets 1/2		CS 1/2 CS 1/2
C3 Cod. 31614100	Combination 3 Baskets 1/3		CS 1/3 CS 1/3 CS 1/3
C4 Cod. 31614200	Combination 1 Baskets 1/2 + 3 Baskets 1/6		CS 1/2 CS 1/6 DX CS 1/6 DX CS 1/6 DX
C4A Cod. 31614300	Combination 2 Baskets 1/3 + 2 Baskets 1/6		CS 1/3 CS 1/3 CS 1/6 SX CS 1/6 DX
C5 Cod. 31614400	Combination 1 Baskets 1/3 + 4 Baskets 1/6		CS 1/3 CS 1/6 SX CS 1/6 DX CS 1/6 SX CS 1/6 DX
C6 Cod. 31615000	Combination 6 Baskets 1/6		CS 1/6 SX CS 1/6 DX CS 1/6 SX CS 1/6 DX CS 1/6 SX CS 1/6 DX