

Quick-mode guide

DIETA MI-MX

START COOK

scroll to select temperature for the product in the kettle.

1...39 °C: **Proving**
40...92 °C: **Gentle cooking**
93...99 °C: **Power cooking**
100...125 °C: **"Light searing"** (not for boiling)

SET TIME

scroll to select cooking time

MEASURE WATER

Set the liters to fill.

SET MIXING


First select mode and then scroll to select speed.

Boiling (potatoes, pasta, rice)	Forward, long pause Speed 10...20
Soups	Forward, long pause Speed 10...30
Sauces, mixing ingredients	Auto-Reverse Speed 80...120
Sauces, simmering	Forward Speed 10...20
Mashing (purees)	Auto-Reverse Speed 80...120
Meat	Auto-Reverse Speed 20...40
Puddings, Porridges	Forward Speed 30...40
Whipped desserts	Auto-Reverse Speed 80...100

CHILLING

Chilling is automatic. Just press chill button and scroll to select the target temperature.

Always use mixing when chilling, as fast as possible.



SAFE-SPEED-MIX

Starts slow speed mixing when lid is open (also when kettle is tilted). Operates only while the button is pressed

TILTING

Kettle tilts when the tilt button is pressed.

NOTE:



Pressing "STOP" will end the current program!

In program end view, you still have an option to return on the same program with "CONTINUE PROGRAM" button.